

# WOCA Floor-Primer

– For priming new or worn floors, panelling, cork tiles, etc.



Easy and effective. *Naturally*



- Water based primer
- Fast drying, 60 min at 20°C
- NMP Free
- Prevents sidebondings
- Easy to sand

## Product info

**Container:** 10L

**Colors:** Natural, White, Grey

**Consumption:** 6-10 m<sup>2</sup>/L  
depending on wood type



## Application area

The Floor Primer is ideal for priming new or newly sanded floors, panelling, cork tiles, etc. Floor Primer also serves as a tough basecoat for further treatment with other water-based WOCA floor Lacquers.

## Result

Floor Primer is a special water-based acrylic wood primer that dries quickly and sands well.

## Application

Floor Primer should be used undiluted and is easy to apply with a brush or 12mm paint roller.

## Aftercare

Requires a subsequent finishing treatment with one of the WOCA lacquers.

## Maintaining and cleaning

According to the chosen finishing treatment.

# How to do...

## – WOCA Floor-Primer



Easy and effective. *Naturally*



1



2



### Tools

Sanding grid, sanding pad, brush or lacquer roller, lacquer-stirrer, lacquer-bowl.

Clean tools with water and soap.

**Floor-Primer is a special water-based acrylic wood primer that dries quickly and sands well. It is ideal for priming new or newly sanded floors, panelling, cork tiles, etc. Floor-Primer also serves as a tough basecoat for further treatment with other water-based WOCA floor Lacquers.**

It is always advisable to do a test application to check that the product is compatible with the material to be primed. If Floor-Primer, White og Grey is applied, no intermediate sanding is done.  
(This is done after the first top coat).

- 1** Floor-Primer is suitable for priming new and untreated wood surfaces indoors.  
It should always be stirred well before use. The surface to be primed must be clean and free from dust, oil, wax, grease and other residues. If necessary, clean surface with Wood Cleaner mixture 1:10 – leave to dry and sand to grit 100 before application.
- 2** Floor-Primer should be used undiluted and is easy to apply with a brush or 12 mm paint roller. It takes 30-60 minutes to dry depending on the humidity and temperature. If primed with Floor-Primer Natural, the floor should be lightly sanded with grit 100, 120 or sanding pad before any of the WOCA floor Lacquers are applied.