WOCA Exterior Cleaner

- For the cleaning of wood decking, garden furniture, cladding/sidings, fences, doors, carports etc.



Preparing today for tomorrow



- Removes moss and algae cover, protects against resettlement
- For furniture's, wood decking's, concrete and tiles
- Manual or machine cleaning (polishing machine)



Application area

For the cleaning of wood decking, garden furniture, cladding/sidings, fences, doors, carports etc.

Result

Cleans the surface and leaves an impregnating effect for 1-2 months.

Application

Use a broad brush, a swab or the like. Scrub with a stiff brush afterwards, in order to remove green growth.

After care

With WOCA Exterior Oil.


Maintaining and cleaning

Use Exterior Cleaner if necessary. For maintenance purposes use Exterior Oil.

How to do...

- WOCA Exterior Cleaner: For the cleaning of wood decking, garden furniture, cladding/sidings, fences, doors, carports etc.







Tools

Medium hard nylon brush, plastic bucket, and a garden hose for the rinsing.

Machine application using a polishing machine is also possible. A detailed instruction is available on the internet.

Clean tools with water and soap.

Exterior Cleaner is for the cleaning of wood decking, garden furniture, cladding/sidings, fences, doors, carports etc. The product removes green growth and dirt. Exterior Cleaner is also very suitable for the cleaning of brickwork and concrete plates.

- 1 Soak the wood with plenty of water. If possible use a garden hose.
- 2 Mix Exterior Cleaner with water in the ratio 1:2 and apply it with stiff brush. By extreme dirt, the Exterior Cleaner may be used undiluted.
- Scrub the soaked wood lengthwise the wood grain till the wood appears clean. Repeat the cleaning if necessary.
- 4 Immediately after cleaning, hose down the surface with water.

- G Clean tools in water.
- 6 Leave the wood to dry for approx. 24 hours. The wood must be completely dry before an oil treatment. Remove fibre rising with sandpaper.