


BASIC





White



Cream




Silver grey



Pear tree



White



Cream



Silver grey



Pear tree



38000  
38010  
38070



38700



38050



38100



38800



38120



38350  
38300



38360



38250



38200

LIMITED OFFER

FUNCTIONAL PART "BASIC" SERIES

Catalogue number	Type	Colour	Rated current In (A)
<b>38000</b>	1 button 1 way switch	White	10
<b>38010</b>	1 button 2 way switch	White	10
<b>38070</b>	1 button cross switch	White	10
<b>38700</b>	1 button 1 way switch with light	White	10
<b>38050</b>	2 button 1 way switch	White	10
<b>38100</b>	Push light switch	White	10
<b>38120</b>	Door bell switch	White	10
<b>38200</b>	German type socket	White	16
<b>38250</b>	German type socket with cover	White	16
<b>38800</b>	Dimmer switch-400W	White	
<b>38350</b>	Phone socket RJ11	White	
<b>38300</b>	Computer socket RJ45	White	
<b>38360</b>	TV socket	White	


**5** YEAR WARRANTY



38801  
38011  
38071



38701



38051




38101



38801



38121



38351  
38301



38361



38251




38201

LIMITED OFFER

## FUNCTIONAL PART "BASIC" SERIES

Catalogue number	Type	Colour	Rated current In (A)
<b>38801</b>	1 button 1 way switch	■ Cream	10
<b>38011</b>	1 button 2 way switch	■ Cream	10
<b>38071</b>	1 button cross switch	■ Cream	10
<b>38701</b>	1 button 1 way switch with light	■ Cream	10
<b>38051</b>	2 button 1 way switch	■ Cream	10
<b>38101</b>	Push light switch	■ Cream	10
<b>38121</b>	Door bell switch	■ Cream	10
<b>38201</b>	German type socket	■ Cream	16
<b>38251</b>	German type socket with cover	■ Cream	16
<b>38801</b>	Dimmer switch-400W	■ Cream	
<b>38351</b>	Phone socket RJ11	■ Cream	
<b>38301</b>	Computer socket RJ45	■ Cream	
<b>38361</b>	TV socket	■ Cream	


**5** YEAR WARRANTY



38802  
38012  
38072



38702



38052



38102



38802



38122



38352  
38302



38362



38252



38202

LIMITED OFFER


FUNCTIONAL PART "BASIC" SERIES

Catalogue number	Type	Colour	Rated current In (A)
<b>38002</b>	1 button 1 way switch	■ Silver grey	10
<b>38012</b>	1 button 2 way switch	■ Silver grey	10
<b>38072</b>	1 button cross switch	■ Silver grey	10
<b>38702</b>	1 button 1 way switch with light	■ Silver grey	10
<b>38052</b>	2 button 1 way switch	■ Silver grey	10
<b>38102</b>	Push light switch	■ Silver grey	10
<b>38122</b>	Door bell switch	■ Silver grey	10
<b>38202</b>	German type socket	■ Silver grey	16
<b>38252</b>	German type socket with cover	■ Silver grey	16
<b>38802</b>	Dimmer switch-400W	■ Silver grey	
<b>38352</b>	Phone socket RJ11	■ Silver grey	
<b>38302</b>	Computer socket RJ45	■ Silver grey	
<b>38362</b>	TV socket	■ Silver grey	


**5** YEAR WARRANTY



38805  
38015  
38075



38705



38055




38105



38805



38125



38355  
38305



38365



38255



38205

LIMITED OFFER


### FUNCTIONAL PART "BASIC" SERIES

Catalogue number	Type	Colour	Rated current In (A)
<b>38005</b>	1 button 1 way switch	Pear tree	10
<b>38015</b>	1 button 2 way switch	Pear tree	10
<b>38075</b>	1 button cross switch	Pear tree	10
<b>38705</b>	1 button 1 way switch with light	Pear tree	10
<b>38055</b>	2 button 1 way switch	Pear tree	10
<b>38105</b>	Push light switch	Pear tree	10
<b>38125</b>	Door bell switch	Pear tree	10
<b>38205</b>	German type socket	Pear tree	16
<b>38255</b>	German type socket with cover	Pear tree	16
<b>38805</b>	Dimmer switch-400W	Pear tree	
<b>38355</b>	Phone socket RJ11	Pear tree	
<b>38305</b>	Computer socket RJ45	Pear tree	
<b>38365</b>	TV socket	Pear tree	

**5** YEAR WARRANTY



2 gangs



3 gangs

SWITCHES AND SOCKETS

BASIC SERIES

LIMITED OFFER

### 2 GANG PANEL "BASIC" SERIES

Catalogue number	Type	Colour
<b>38900</b>	2 gang	White
<b>38901</b>	2 gang	Cream
<b>38902</b>	2 gang	Silver grey
<b>38905</b>	2 gang	Pear tree

LIMITED OFFER

### 3 GANG PANEL "BASIC" SERIES

Catalogue number	Type	Colour
<b>38910</b>	3 gang	White
<b>38911</b>	3 gang	Cream
<b>38912</b>	3 gang	Silver grey
<b>38915</b>	3 gang	Pear tree

**5** YEAR WARRANTY