Congratulations on the purchase of your new PetScribe[™]/N'Scriber[™] engraving system. The following manual serves as a guide on proper unpacking, set up, installation and usage for this unit.

ITEMS INCLUDED ARE: PetScribe[™]/N'Scriber[™] unit, keyboard, power cord, tag holder, assorted tags, split rings.

TABLE OF CONTENTS

PgSection
1Welcome to PetScribe™/N'Scriber™
2
3Installing/Changing the Tag Holder
5 Engraving a Tag
6
7Change Lang. / Double Engraving / Change Font
8Registration
9

To report problems, call 1-888-600-8247



Unpacking your PetScribe[™]/N'Scriber[™]







Fig. 2-1 Place shipping carton on a flat surface with red arrows pointing up. Open carton and remove the top protective foam insert.Fig. 2-2 Next remove the insert containing the keyboard and supply of tags.





Fig. 2-3 The power cord is located inside the box beside the unit.

Fig. 2-4 The PetScribeTM/N'ScriberTM can now be removed from the carton. It's a tight fit so you may need help to hold the box. Grab the unit by the front and back, then pull straight up. After clearing the box place unit on a desk or counter where it will operate.




Powering up your PetScribe[™]/N'Scriber[™]

Fig. 2-5 Insert power cord into the extension on the bottom of the unit. DO NOT PLUG INTO THE WALL SOCKET AT THIS TIME.

Fig. 2-6 Insert keyboard plug into the receptacle on the front of the unit. The plug is keyed so be sure not to force it.

Fig. 2-7 Plug the unit into the wall, then flip the power rocker switch located under the front right corner.





Current Tag Style: Small Circle

- F1: Engrave Tag (1x)
- F2: Change Tag Style
- F3: Change Font Standard




Fig. 3-1 The tag holder was included with the unit. It's located in the foam insert with the keyboard and tags.



Fig. 3-2 Press "*F2*" on the keyboard. When the following screen appears, use the "*Up*" and "*Down*" arrow keys to select the correct tag style, then press "*F1*".

- Select Tag (Use †/↓ Keys) F1: Select F10: Cancel =
 - Large Heart Heart Small Circle Large => Circle Small
- Fig. 3-3 The door will open and the platform will move out to the install position.



Note: An [H] after a tag style means the tag engraves Horizontaly, while a [V] means Vertical. See the template section of this manual for a graphic representation.




Fig. 3-4 Install the tag holder onto the platform with the style to be engraved to the front.

Guide Pins








Fig. 4-1 The two guide pins will insure the holder is properly aligned.







The following screen should be displayed, press "F1" after the correct tag holder is installed.









Curr	ent Tag Style: Small Circle Engrave Tag (1x) Change Tag Style Change Font - Standard
F1:	Engrave Tag (1x)
F2:	Change Tag Style
F3:	Change Font - Standard

4



Engraving a Tag

The unit will display the following input screen indicating the maximum number of lines the tag can hold. Use the keyboard to enter the tag information.

5	Heart Large Lines Max	> >	_	
	F1: Engrave F10: Cancel			
	FIU: Cancer	•		

The text will be centered automatically on the tag.




Fig. 5-1 When finished entering the information, press "FI" and the platform will be pulled into the unit, the door will close, and the tag will be engraved. When the engraver is finished, the door will open and the platform will extend the finished tag.

Remove the engraved tag. If desired, additional tags of the same style may be engraved at this time. The information on the additional tags may be updated if required then press "F1" to begin the engraving process.




Fig. 5-2 The size of the characters changes with the number of lines and characters entered. Fewer lines and characters on a line result in larger letters.

Approximately two minutes after the last tag is engraved the door will close and the main menu screen will be displayed. The unit is now ready for new commands.



Tag Counts

While the Main Menu is displayed press the "Home" key on the keyboard. The unit will display the following screen.

Total	: 12345
	Bone: 123
	Large Heart: 123
	Bell: 123
	Military: 123
	Large Circle: 123
	Luggage: 123
	Oval: 123
	Rosette: 123
	Small Circle: 123
	Small Heart: 123
	Large Rivet: 123
	Small Rivet: 123
	Large Decor: 123
	Small Decor: 123
	Ornament: 123

Use the "Arrow" keys on the keyboard to scroll down and up to see additional tag styles.

When you're finished checking tag counts press the "Esc" key to return to the Main Menu.

Software Update

- Turn off the power
- Insert the compact flash card into the "Update Port"
- Turn on the power and the following screen will appear

Press "D" To download Firmware Press "Enter" to Not Download Firmware

- Press "D"
- When finished, power down the unit.
- Remove the compact flash card.

This function will be used to add new tag styles when they become available. Each software update will come with additional instructions to complete the update.



Changing the Language

While the main menu is displayed press the "Ctrl" then the "L" keys on the keyboard. The unit will display the following screen.

Current Lanuage is:	English
Change Language to:	English
Use 1/1 arrows to change	ge selection.
F1: Select	F10: Cancel

Use the "Arrow keys on the keys on the keyboard to scroll the "Change Language to:" field to the correct language then press "F1" to make the change.

Double Engraving


While the main menu is displayed press the "Alt" then "D" keys on the keyboard. The unit will display the following screen.

To return to single engrave press "Alt" "D" again.

You have selected to Engrave each character Twice.

Changing Fonts

While the main menu is displayed press the "F3" key on the keyboard. The unit will switch to the alternate font.



While the main menu is displayed pressing "Ctrl" "F" will remove the Diva Font option.

pet C.

Registration Information

Your serial number is located on the bottom of your PetScribe[™]/N'Scriber[™] unit. We strongly advise you to record this number in this booklet and in a place for safe keeping in the case of damage or theft.





PetScribe[™]/N'Scriber[™] Templates


These templates are laid out to photocopy. Supply these to clients to fill out prior to engraving custom tags.





I.D. Tag Templates


pet






0 8l# #1A THOR 9866 AUBURN RD. BOMONT MA 87689 TEL 619-323-0468 Fixture p/n 11238-01 Owner: (Please Print Clearly) Name: Address: _____ City: _____ State ____ Zip _____ Phone # _____






Owner:	(Please Print Clearly)
Name:	
Address: _	
City:	State Zip
Phone #	















Fixture p/n 11240-03

STEVEN RANDALL 171 S. EXTENSION RD 14 TEMPE ARIZONA 85284 480-555-1234 STEVE@NETZIP.COM

_					_						
ſ											
ſ											
Ī											
Ī											
Ī											

Owner:	(Please Print Clearly)
Name:	
Address: _	
City:	State Zip
Phone #	







Fixture p/n 11240-03

HAPPY BIRTHDAY 09-07-2003 LOVE MOM & KIDS


Owner:	(Please Print Clearly)
Name:	
Address: _	
City:	State Zip
Phone # _	















pet
























Engraved text will be automatically centered and sized to the maximum space available.



pet










Owner:	(Please Print Clearly)
Name:	
Address: _	
City:	State Zip
Phone #	














Oval Template


pet









Owner:	(Please Print Clea	arly)		
Name:				
Address: _				
City:		State	Zip	
Phone #				








Owner:	(Please Print Clearly)
Name:	
Address:	
City:	State Zip
Phone #	



pet









Owner:	(Please Print Clearly	<i>(</i>)	
Name:			
Address: _			
City:		State	_ Zip
Phone #			





Key Templates


























Tag Fixtures








Fixture p/n 11240-03




Fixture p/n 11240-04




Fixture p/n 11238-02





Tag Fixtures





Fixture p/n 11240-06











NOTES: